


1



4



8


9




10

Description / Model*	Part number
Spare electrical parts:	
1 Regulation thermostat (RE/LE, RE/L)	WEG01404
2 On/Off switch, orange indicator (RE/LE)	WSX02012
3 Noryl flow switch	WSX03025
4 Safety thermostat 63° (RE/LE)	WIN01641
7 Elec. connection terminals (RE/LE)	WCC01289
9 8 Shunt for switching from three to single phase	WCC01287 WCC01288
10 Contactor DILM 9-10	WCF01066
12 11 Right resistance 3 Kw titanium	WEG01412
Cross support	WIB01610
12 11 Right resistance 6 Kw titanium	WEG01413
Cross support	WIB01610
12 11 Right resistance 9 Kw titanium	WEG01414
Cross support	WIB01610
12 11 Right resistance 12 Kw titanium	WEG01415
Cross support	WIB01610
A Three phase safety thermostat (RE/N, RE/L)	WEG01407
B Regulation thermostat Bulb 6	WEG01405
C Pressure switch 153 ml/b	WCE03365
Other	
13 Body RE/L3 and 6 kW	WIB01606
13 Body RE/L9 and 12 kW	WIB01605
19 15 2 1/2 union connections Ø 63/50 (RE/LE)	W40RDL
24 16 Height adjuster	WIB01611
Joint	WJW01667
17 Box	WIB01612
14 Split left/right nut	WIB01608


* For all orders for spare parts please give the serial number of the warmer.



RE/L FITTED



11



A



B



C